


Air Valve Assembly - Manual Configuration



**Typical Air Release Assembly Detail
Manual Configuration**