

Float Arrangement Diagram



Oreco Systems®
Incorporated

814 AIRWAY AVENUE
SUTHERLIN, OREGON
97479-9012

TELEPHONE:
(541) 459-4449

FACSIMILE:
(541) 459-2884

Check the appropriate box for the float function (color code) used in your system.

<p><input type="checkbox"/> (YG)RW • <i>Factory Standard</i> •</p> <p>*Terminal Link Rail is required (factory installed).</p> <p>For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-SSF-125</p>	<p><input type="checkbox"/> YRW</p> <p>*Remove pre-installed Terminal Link Rail from terminals. See Panel Wiring Diagram for instructions.</p> <p>For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-SSF-126</p>	<p><input type="checkbox"/> YGRW</p> <p>*Remove pre-installed Terminal Link Rail from terminals. See Panel Wiring Diagram for instructions.</p> <p>For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-SSF-127</p>
---	---	--

Float Types

Typical Oreco float model: A
Specs: contact - normally open
differential - no minimum
power rating - signal
Possible substitutions: B,C,D

A high level condition in the sand filter will disable the septic tank pump in auto mode.

Control Panel Series

MVP-SSF PT RO /

For use in two pump systems, septic tank side.

Drawing No.

EDW-FA-SSF-110

EDW-FA-SSF-110
Rev 1.4 © 08/28/02