

# Orenco® Prelos® 1500 Processor, 50Hz

## Applications

Orenco's Prelos 1500 Processor provides complete, integrated storage, filtration, and pumping of wastewater for on-lot portions of Prelos Sewer systems and other pressurized liquid-only sewers or dispersal systems.

## General

The Prelos Processor is the core of the Prelos Sewer System: an innovative technology based on 40 years of proven sewer solutions. The tank stores and passively treats solid waste, while the patent-pending pump vault and filter separate and pump liquid effluent.\*

All Prelos 1500 Processors install as a unit, to reduce errors. The standard 750mm (30in) diameter access riser and optional additional 600mm (24in) diameter access riser provide easy access to the tank interior, and the passively self-cleaning filter can be removed without removing the pump vault, pump, or discharge assembly, simplifying O&M and keeping related costs down.



\* Tank covered under United States Patent #10,392,281

## Selected Models



PRELOS1500(50HZ)-24, PRELOS1500(50HZ)-36,  
PRELOS1500(50HZ)-24-24, PRELOS1500(50HZ)-36-36

## Product Code Diagram

PRELOS 1500 (50HZ) -  -



The Prelos 1500 50Hz Processor offers complete, integrated storage and pumping of wastewater in a simple, effective package.



- |                              |                           |                        |
|------------------------------|---------------------------|------------------------|
| 1. Inlet                     | 6. Access riser           | 11. Pump               |
| 2. Inlet tee                 | 7. Access lid             | 12. Discharge assembly |
| 3. Support column            | 8. Pump vault             | 13. ClickTight™        |
| 4. Baffle wall (full-length) | 9. Biotube® filter        | 14. Discharge          |
| 5. Baffle pass-through       | 10. Float switch assembly | 15. Lifting bracket    |

### Tank, Riser, and Lid

The Prelos 1500 Processor's meander-style tank has a patented design for superior performance. It's tough, impact resistant, and light enough to install with small equipment. The standard 750mm (30in) access riser, optional additional 600mm (24in) riser, and access lids are designed to provide strong, secure access to components inside of the Prelos 1500 Processor.

### Materials of Construction

Access lid	Fiber-reinforced polymer (FRP), structural foam
Access lid hardware	Stainless steel
Access riser	FRP
Baffle walls	ABS
Inlet and inlet tee	ABS
Support column	PVC, ABS
Tank body	DCPD

### Dimensions

<b>A</b> Tank height, mm (in)	1829 (72)
<b>B</b> Tank outside diameter, mm (in)	2667 (105)
<b>C</b> Tank width, flat-to-flat, mm (in)	2565 (101)
<b>D</b> Lid outside diameter, mm (in)	838 (33)
<b>E</b> Riser inside diameter, mm (in)	749 (29.5)
<b>F</b> Depth, nominal operating volume, mm (in)	1448 (57)
Optional secondary riser lid outside dia., mm (in)	610 (24)
Optional secondary riser inside dia., mm (in)	597 (23.5)
Tank nominal operating volume, L (gal)	5678 (1500)
Tank total volume, L (gal)	6768 (1788)
Average volume at operating depth, L/mm (gal/in)	4 (25)
Prelos Processor weight, nominal, kg (lbs)	354-395 (780-870)

## Pump Vault


Orenco's Prelos 1500 Processor's patent-pending pump vault is designed to be passively self cleaning for reduced maintenance and service needs, with no need to remove the vault from the processor for cleaning.

### Materials of Construction


Vault body	Polyethylene
------------	--------------

### Vault Dimensions


	mm (in)
<b>A</b>	470 (18.50)
<b>B</b>	405 (15.94)
<b>C</b>	1664 (65.50)
<b>D</b>	386 (15.20)



Prelos pump vault, top view



Prelos pump vault, side-cutaway view



Prelos pump vault, front view

## Biotube Effluent Filter

The Prelos 1500 Processor's Biotube effluent filter is designed for effective filtration of effluent and passive self cleaning for long maintenance cycle intervals.

### Materials of Construction

End plates	DCPD
Filter tubes	Polypropylene
Handle assembly	Sch. 40 PVC
Screws	Stainless steel


### Dimensions

	mm (in)
<b>A</b>	419 (16.5)
<b>B</b>	254 (10.0)


### Performance

Biotube mesh opening, mm (in)*	3 (0.125)
Total filter flow area, m <sup>2</sup> (ft <sup>2</sup> )	0.37 (4.0)
Total filter surface area, m <sup>2</sup> (ft <sup>2</sup> )	1.3 (14.0)


\*1.6mm (0.062in) filter mesh available



Biotube filter cartridge, top view



Biotube filter cartridge, side view



Biotube filter cartridge, front view

## 100mm (4in) Effluent Pump

Pumps used in Prelos 1500 Processors are Orenco's PF-Series pumps. They're field serviceable with common tools and, in internal testing, have a minimum 24hr run-dry capability (liquid end) with no deterioration in pump life or performance. These pumps are equipped with Type SOOW 600V power cords (suitable for Class I, Division 1 and 2 applications); they also meet UL requirements and are CSA certified to US and Canadian safety standards for effluent pumps.

### Materials of Construction

Connector	Glass-filled thermoplastic, silicone
Diffusers	Glass-filled PPO
Discharge	Glass-filled polypropylene
Discharge bearing	Engineered thermoplastic (PEEK)
Impellers	Acetal
Intake screens	Polypropylene
Lubricant	Deionized water, propylene glycol
Suction connection, drive shaft, coupling, shell	Stainless steel

### Specifications

Nominal flow, L/sec (gpm)	0.6 (10)
Length, mm (in)	584 (23)
Weight, kg (lb)	12 (26)
Discharge, in (nominal)	1.25
Impellers	6


### Performance

kW (hp)	0.37 (0.5)
Design flow amps	3.9
Rated cycles/day	300
Minimum liquid level, mm (in)*	432 (17)

\* Minimum liquid level is for a single pump installed in a pump vault.

## Pump Curve

This graph shows the pump's performance range and the relationship between flow (L/sec or gpm) and pressure (TDH).



## HDA-Series Discharge Assembly

Discharge assemblies used in Prelos 1500 Processors are designed for durability and ease of maintenance.


### Materials of Construction

Anti-siphon valve	Sch. 80 PVC, EPDM, stainless steel
Discharge nipple	Sch. 80 PVC
Flexible hose	Reinforced EPDM
Flow control disc	Sch. 80 PVC
Hose fittings, tee fitting, mounting screws	Stainless steel
In-line check valve	Sch. 80 PVC, EPDM, stainless steel
Mounting plate	ABS
Quick-disconnect	Glass-filled thermoplastic

### Working Pressures and Dimensions

Unit working pressure, kPa (psi)	1034 (150)
Height, mounting plate, mm (in)	178 (7)
Width, mounting plate, mm (in)	178 (7)
Diameter, discharge nipple, in*	1.25
Diameter, flow control disc orifice, mm (in)	6.35 (0.25)

\* Contact your Orenco distributor about fittings to connect discharge assemblies to metric-sized piping.



1. Hose barb
2. Crimp sleeve
3. Flexible hose
4. Hose clamp
5. Tee fitting
6. Anti-siphon valve
7. In-line check valve
8. Quick-disconnect
9. Quick-disconnect receiver
10. Mounting plate
11. Discharge nipple

HDA-Series discharge assembly

## Float Switches



Float switches used in Prelos 1500 Processors are UL listed and CSA certified for use in water or sewage. To simplify accessing and servicing, the float switch assembly has been incorporated into the Biotube filter handle.

### Materials of Construction

ClickTight connector	Glass-filled thermoplastic, silicone
Float collar	ABS
Float cord	Flexible, 2 conductor (UL, CSA), SJOW; CPE cord jacket with EPDM insulated conductors
Float housing	Impact-resistant, noncorrodible polypropylene for use in liquids up to 60°C (140°F)

### Float Switch Specifications

Float	State	Type
P	Normally open	Mechanical



1. Float switch
2. Float switch cord
3. Float switch connector

ClickTight mechanical float switch

## ClickTight


Orenco's ClickTight provides secure, moisture-resistant cable connections between the pump, float switches, and control panel in the Prelos 1500 Processor. ClickTight is UL listed for the US and Canada.

### Materials of Construction

Cable	PVC/nylon, annealed copper; Type TC
Connectors	Glass-filled thermoplastic, silicone
Fastener	Stainless steel
Housing	ABS
O-ring	Buna-N
Potting compound	Urethane

### Specifications

Cable rating	14AWG; 3 conductor; UL TC-ER 600V (pump) 18AWG; 2-8 conductor; UL TC-ER 600V (float)
Float switch connectors	double-pole
Pump connector	triple-pole
Maximum cable length, m (ft)	19 (62)



ClickTight

## S2(50HZ)HR Control Panel

The Prelos 1500 50Hz Processor uses Orenco's S2(50HZ)HR control panel, which is ideal for Prelos Sewers and other effluent sewer applications.

### Materials of Construction


Enclosure	UV-resistant fiberglass, UL Type 4X
Hinges	Stainless steel

### Dimensions, mm (in)

Height	292 (11.5)
Width	236 (9.3)
Depth	137 (5.4)

### Specifications

Panel ratings	230VAC, 1.5kW (2hp), 9A, single-phase, 50Hz
Motor-start contactor	9FLA, 1.5kW (2hp), 50Hz; 2.5 million cycles at FLA
Circuit breakers	230VAC, 10A, single-pole (control) 230VAC, 20A, single-pole (pump)
Toggle switch	Single-pole, double-throw HOA switch
Audio alarm	95dB at 600mm (24in), warble-tone sound; gasketed, UL Type 4X (IP 66)
Redundant high-on relay	230VAC, DIN rail mounted; provides a secondary pump-on signal during high-level conditions
Audio alarm silence relay	230VAC, automatic reset, DIN rail mount
Visual alarm	22mm (7/8in) diameter red lens, "push-to-silence," 230VAC LED, UL Type 4X



S2(50HZ)HR control panel

1. Motor-start contactor
2. Circuit breakers
3. Toggle switch
4. Audio alarm
5. Redundant high-on relay
6. Audio alarm silence relay
7. Visual alarm